

wiggleboard T1/T2

INSTRUCTION SHEET

Thank you for purchasing the Wiggleboard. Please read these instructions carefully before using your Wiggleboard and save this sheet for future reference.

PRODUCT INTRODUCTION

The Wiggleboard is specially designed to be a safer, easier-to-ride, skateboarding option for children, ages 6-13, that is also entertaining and challenging for older teens and adults. It is not only a unique, fun-to-ride skateboard that aids in strengthening the spine and core muscles; it can also help younger children develop the balance, strength, coordination, and confidence needed to ride other skateboards.

- Innovative three-wheel design and unique wide plastic platform provide added stability and versatility.
- 360° rotating inline skating wheel design offers exceptional maneuverability.
- To prevent danger caused by falling, loss of control, and collisions, please learn how to ride the Wiggleboard safely.
- This sheet contains all riding instructions and precautions, and users must read it carefully and follow the instructions listed.
- IDbabi® can not be held liable for damage or injury caused by failure to understand or follow the cautions, warnings, and instructions listed on this sheet.



CAUTION

- Read the instruction sheet and warning labels before riding.
- Please assemble three wheelsets according to the instructions. Check the tightness of the fixing screws and make sure that they are locked firmly before use.
- Do not jump the Wiggleboard or ride off curbs or ramps; it is not designed to withstand the full impacts of riding a regular skateboard or scooter and damage to the Wiggleboard and/or bodily injury can result.
- When carrying or transporting Wiggleboard, avoid dropping from heights, violent crashes or impacts.
- The Wiggleboard is designed not to roll backward. Use caution when riding up or around curves or inclined surfaces to avoid falls and possible injury.
- To avoid risk of injury, do not attempt to slow down or stop Wiggleboard by putting or dragging hands or feet on ground.
- Do not use non original accessories, otherwise the safety performance of wiggleboard will be affected.
- In case of product damage or safety accident caused by abnormal use, the brand manufacturer and distributor shall not bear relevant responsibilities.






The product is not suitable for children under 3 years of age. Due to the content of small parts, there is a risk of swallowing, which is a choking hazard.

PLEASE CAREFULLY READ THIS INSTRUCTION SHEET.

Failure to follow the basic instructions given and safety precautions listed for users on this instruction sheet can lead to damage to your Wiggleboard, serious bodily injury, or even death.

PRODUCT PARTS



CARE AND MAINTENANCE

- The Wiggleboard is designed for use on paved surfaces in dry conditions.
- Do not ride Wiggleboard in rain or other inclement weather, on wet or icy surfaces, or through or near puddles of water, mud, sand, stones, gravel, debris or on rough terrain.
- Do not allow the product to come into contact with oily, acidic or alkaline liquids, otherwise the product will be corroded, deformed or cracked.
- When cleaning, first use a wet towel to add a small amount of mild detergent to wipe off the dirt, and then dry the product surface with a dry towel.
- Prolonged exposure to UV rays, rain and the elements will cause damage to the Wiggleboard and/or its inline skate wheels. Store indoors when not in use.
- Pay attention to the wear condition of the bearing and wheels. If they need to be replaced, please purchase the original accessories. You can ask the customer service center for assistance.


RIDING TIPS

- Turning is easy. Shifting weight to one side or the other will make the Wiggleboard turn left or right.
- Try multiple riding positions for added fun. Stand, squat, sit or kneel on Wiggleboard.
- Two people can even ride the Wiggleboard together-one sitting and one standing or both riders standing.
- Wiggleboard provides its own resistance and will slowly roll to stop when the rider stops wiggling. If riding Wiggleboard while standing, you can jump off Wiggleboard in an emergency situation and it will roll to stop. Under the premise of ensuring safety, you can brake wiggleboard with one foot on the ground and one foot step on it.

RIDING INSTRUCTIONS

The best places to ride the Wiggleboard are on flat (slope less than 5°), slightly rough paved surfaces such as cement, smooth asphalt, and playing surfaces like outdoor basketball or tennis courts.

The most popular riding position for the Wiggleboard is both feet parallel, slightly apart and facing forward, with knees slightly bent and heels toward the back of the board. To propel the Wiggleboard forward, twist waist and wiggle hips from side to side. There are four basic riding positions for the Wiggleboard:




(1) Front Stance

Stand upright. Slightly bend knees and wiggle hips/twist waist from side to side to create forward motion.




Sit cross-legged on Wiggleboard.
Twist back and forth at waist.



② Squatting

Squat on board (deep squat or knee bend). Twist waist left and right.



4 Skateboard Stance Stand with knees bent and feet apart and angled slightly sideways.

Twist waist/wiggle hips.

TIPS Turning: Shifting weight to one side or the other will make the Wiggleboard turn left or right.

WARNING Do not use Wiggleboard on steep slopes, steps, near water or roads When two people are riding together, understand that there is an increased risk of injury from falling, collision, or loss of control. Do not exceed weight limit of 220 pounds (T1)/165 pounds (T2). Always wear flat, closed-toe shoes and ASTM, CPSCor Snell-certified helmets and appropriate safety gear such as knee and elbow pads to minimize chance of injury. Exercise additional caution due to increased riding weight.

PACKAGE CONTENTS

Name	Quantity
Wiggleboard	1 pcs
Instruction Sheet	1 pcs
Wheel Set	3 set
Allen Wrench	1 pcs

PRODUCT INFO

Name	Wiggleboard	
Model	T1	T2
Dimensions	54 x 40 x 14 cm	
Made of	Plastic, Metal	
	PU	Nylon Fiber
Executive standard	GB-6675	
Net weight	7.17 lbs./3.25 kg	6.61 lbs./3kg

ASSEMBLY INSTRUCTIONS OF WHEELSET

Code	Name	PCS
Α	Wiggleboard	1
В	Connecting Shaft	3
С	Bearing	6
D	Wheelset	3
E	M8 x 12 Hex Screw	3
F	5mm Allen Wrench	1


STEP ONE: Use Allen Wrench (F) to remove the M8x12Hex Screw (E) from Connecting Shaft (B).

STEP TWO: Place one Bearing (**C**) on Connecting Shaft (**B**) on Wiggleboard (**A**).

STEPTHREE: Seat Wheelset (**D**) on Connecting Shaft (**B**).

STEPFOUR: Place Second Bearing (**C**) on Connecting Shaft (**B**).

STEP FIVE: Insert M8 x 12 Hex Screw (E).
STEP SIX: Tighten Hex Screw (E) with Allen Wrench





Distributor:

ONTROPS sp. z o.o. ul. Hozjusza 1, 11-041 Olsztyn

Tel.: +48 73O-125-825 www.ontrops.com

Manufacturer:

GoodMen Household Products Technology(Shenzhen) Co., Ltd. 408X, No. 3, Xitou Industrial Zone, Minzhi Street, Longhua District, Shenzhen, China

Tel.: +86-755-33268138 **www.idbabi.com**